



<i>Team</i>	<i>Date:</i>
-------------	--------------

<i>Team Member:</i>

Demerit: 2 demerits for each omission, 1 demerit for wrong order (step 10-17 only)

<i>For Failure to:</i>	<i>Demerit</i>
------------------------	----------------

1	Perform positive pressure leak test on tester (Test-it 6100 or RZ 7000)	
---	---	--

2	Inspect apparatus, cylinder test date, belt, and lanyard	
---	--	--

3	Connect BG4 to tester	
---	-----------------------	--

4	Test no pressure warning	
---	--------------------------	--

5	Test inhalation valve	
---	-----------------------	--

6	Test exhalation valve	
---	-----------------------	--

7	Test pressure relief valve	
---	----------------------------	--

8	Test moisture relief valve	
---	----------------------------	--

9	Perform positive pressure leak test	
---	-------------------------------------	--

10	Open cylinder	
----	---------------	--

11	Perform High Pressure Leak Test	
----	---------------------------------	--

12	Test constant dosage rate	
----	---------------------------	--

13	Test the bypass	
----	-----------------	--

14	Test the minimum valve activation pressure	
----	--	--

15	Record O2 cylinder pressure and close cylinder valve	
----	--	--

16	Test the low pressure alarms	
17	Observe battery test and shut off sentinel	
18	Inspect facemask	
19	Install cover	
20	Place date on seal and install on BG4	
21	Place BG4 in storage location (bag, case, drawer)	
22	Record all information on BG4 Record sheet	

Total Demerits:

Signature of Judge