



Team	Date:
-------------	--------------

Team Member

Demerit: 2 demerits for each omission
1 demerit for wrong order

For Failure to:	Demerit
------------------------	----------------

1	Push and hold center button until lights flash	
---	------------------------------------------------	--

2	Wait for screen to display the gases with numbers	
---	---------------------------------------------------	--

3	Push center button twice to get menu at the top of screen	
---	-----------------------------------------------------------	--

4	Scroll to sensors with right button	
---	-------------------------------------	--

5	Scroll to calibrate	
---	---------------------	--

6	Push center button	
---	--------------------	--

7	Push OK (center button) (zeros and calibrates O2) (will beep when done)	
---	-------------------------------------------------------------------------	--

8	Push OK (center button)	
---	-------------------------	--

9	Apply cup by pushing down when "apply CO" is on screen	
---	--------------------------------------------------------	--

10	Turn on gas	
----	-------------	--

11	Allow unit to calibrate (each gas separately but automatically) (will beep after each gas is complete)	
----	--------------------------------------------------------------------------------------------------------	--

12	Record results	
----	----------------	--



13	Allow unit to alarm	
14	Turn off gas and remove cup	
15	Allow gases to clear	
16	Push center button twice to get menu at the top of screen	
17	Clear peaks	
18	Return to operating mode	
19	Report to Captain	
Total Demerits:		

Signature of Judge:

--